

Artos PN	Anvil for Wire Diameter	Number in Manual
918-833	.035 - .032	WFC-035
919-408	.038 - .035	WFC-038
918-990	.041 - .038	WFC-041
919-409	.044 - .041	WFC-044
919-410	.048 - .044	WFC-048
919-411	.052 - .048	WFC-052
919-412	.056 - .053	WFC-056
919-413	.060 - .057	WFC-060
919-414	.064 - .060	WFC-064
919-415	.068 - .064	WFC-068
919-146	.072 - .068	WFC-072
919-405	.076 - .072	WFC-076
919-417	.080 - .076	WFC-080
919-418	.085 - .080	WFC-085
917-225	.090 - .085	WFC-090
917-226	.095 - .090	WFC-095
919-419	.100 - .095	WFC-100
917-906	.105 - .100	WFC-105
917-274	.111 - .105	WFC-111
917-605	.117 - .111	WFC-117
917-606	.123 - .117	WFC-123
919-420	.130 - .123	WFC-130
917-607	.137 - .130	WFC-137
917-608	.144 - .137	WFC-144
917-910	.152 - .144	WFC-152
919-421	.160 - .152	WFC-160
917-609	.168 - .160	WFC-168
919-422	.177 - .168	WFC-177
917-911	.186 - .177	WFC-186
917-275	.195 - .186	WFC-195
919-423	.205 - .195	WFC-205
919-424	.215 - .205	WFC-215
919-425	.226 - .215	WFC-226
919-426	.238 - .226	WFC-238
917-912	.250 - .238	WFC-250